

Repetier-Firmware configuration tool for version 0.92.9 version

Start	General	Mechanics	Tools	Features	User Interface	Manual	Download
--------------	----------------	------------------	--------------	-----------------	-----------------------	---------------	-----------------

Stepper

- Enable backlash compensation (ENABLE_BACKLASH_COMPENSATION)
- Allow quad stepping. Required for frequencies larger 24000 Hz on AVR systems and for frequencies larger 200000 Hz on ARM based systems. (ALLOW_QUADSTEPPING)

Disable steppers after inactivity of
STEPPER_INACTIVE_TIME

[s]

[Info about Steppers](#)

Disable as much as possible after inactivity of
MAX_INACTIVE_TIME

[s, 0 = disabled]

Delay stepper high signal
STEPPER_HIGH_DELAY

[microseconds] Needed for gantry systems and due boards.

Delay stepper direction signal
DIRECTION_DELAY

[microseconds] Needed only for slow stepper drivers.

Jerk XY moves
MAX_JERK

[mm/s]

[Info about Jerk](#)

Z-Jerk
MAX_ZJERK

[mm/s]

X axis stepper motor

Stepper socket
X_(STEP|DIR|ENABLE)_PIN

X motor

Resolution
X_AXIS_STEPS_PER_MM

160 [steps per mm]

Max. travel speed
MAX_FEEDRATE_X

200 [mm/s]

Homing speed
HOMING_FEEDRATE_X

40 [mm/s]

Travel acceleration
MAX_TRAVEL_ACCELERATION_UNITS_PER_SQ_SECOND_X

1000 [mm/s²]

Print acceleration
MAX_ACCELERATION_UNITS_PER_SQ_SECOND_X

1000 [mm/s²]

Invert direction (INVERT_X_DIR)

Invert enable signal (X_ENABLE_ON)

Disable when unused (DISABLE_X)

Mirror motor signals to other stepper driver (FEATURE_TWO_XSTEPPER)

Dual X Axis (0 = ext 0, 1 = ext 1) (DUAL_X_AXIS)

Y axis stepper motor

Stepper socket
Y_(STEP|DIR|ENABLE)_PIN

Y motor

Resolution
Y_AXIS_STEPS_PER_MM

160 [steps per mm]

Max. travel speed
MAX_FEEDRATE_Y

200 [mm/s]

Homing speed
HOMING_FEEDRATE_Y

40 [mm/s]

Travel acceleration

1000

MAX_TRAVEL_ACCELERATION_UNITS_PER_SQ_SECOND_Y

[mm/s²]**Print acceleration**

MAX_ACCELERATION_UNITS_PER_SQ_SECOND_Y

1000

[mm/s²]

- Invert direction (INVERT_Y_DIR)
- Invert enable signal (Y_ENABLE_ON)
- Disable when unused (DISABLE_Y)
- Mirror motor signals to other stepper driver (FEATURE_TWO_YSTEPPER)

Z axis stepper motor**Stepper socket**

Z_(STEP|DIR|ENABLE)_PIN

Z motor

Resolution

ZAXIS_STEPS_PER_MM

6400

[steps per mm]

Max. travel speed

MAX_FEEDRATE_Z

2

[mm/s]

Homing speed

HOMING_FEEDRATE_Z

2

[mm/s]

Travel acceleration

MAX_TRAVEL_ACCELERATION_UNITS_PER_SQ_SECOND_Z

100

[mm/s²]**Print acceleration**

MAX_ACCELERATION_UNITS_PER_SQ_SECOND_X

100

[mm/s²]

- Invert direction (INVERT_Z_DIR)
- Invert enable signal (Z_ENABLE_ON)
- Disable when unused (DISABLE_Z)
- Prevent z stepper disabling on stepper timeout.
(PREVENT_Z_DISABLE_ON_STEPPER_TIMEOUT)
- Mirror motor signals to other stepper driver (FEATURE_TWO_ZSTEPPER)

Mirror motor signals to third stepper driver (FEATURE_THREE_ZSTEPPER)

**Modify acceleration
with increasing z
position**

INTERPOLATE_ACCELERATION_WITH_Z

Don't interpolate ▼

Endstops

Always check endstops. Only enable if you have no cross talk from your motors, which could trigger wrong signals causing the print to skew. (ALWAYS_CHECK_ENDSTOPS)

X homing in negative direction direction (towards min endstop). (X_HOME_DIR)

Y homing in negative direction direction (towards min endstop). (Y_HOME_DIR)

Z homing in negative direction direction (towards min endstop). (Z_HOME_DIR)

Homing order

HOMING_ORDER

X, Y then Z ▼

X min

ENDSTOP_PULLUP_X_MIN/ENDSTOP_X_MIN_INVER

Switch on GND, normally clos ▼

Pin

X_MIN_PIN

X min endstop ▼

Y min

ENDSTOP_PULLUP_Y_MIN/ENDSTOP_Y_MIN_INVER

Switch on GND, normally clos ▼

Pin

Y_MIN_PIN

Y min endstop ▼

Z min

ENDSTOP_PULLUP_Z_MIN/ENDSTOP_Z_MIN_INVER

Switch on GND, normally clos ▼

Pin

Z_MIN_PIN

Z min endstop ▼

X max

ENDSTOP_PULLUP_X_MAX/ENDSTOP_X_MAX_INVER

Not installed ▼

Pin

X_MAX_PIN

Disabled / No pin assigned ▼

Y max

ENDSTOP_PULLUP_Y_MAX/ENDSTOP_Y_MAX_INVER

Not installed ▼

Pin

Y_MAX_PIN

Disabled / No pin assigned ▼

Z max

ENDSTOP_PULLUP_Z_MAX/ENDSTOP_Z_MAX_INVER

Not installed ▼

Pin

Z_MAX_PIN

Disabled / No pin assigned ▼

You can test the endstops with the M119 command. As long as they are not triggered, the returned message should show "L" as signal state.

Endstop distance after homing

ENDSTOP_{X|Y|Z}_BACK_ON_HOME

[mm for X,Y and Z]

This is the distance, that the extruder will have to endstops after homing is finished. Use this if you want to prevent triggering when you are near endstops or for delta printers to go a bit lower, so you can select between extruders without hitting the endstop.

Pause handling

Retract on pause

RETRACT_ON_PAUSE

[mm]

Pause start script

PAUSE_START_COMMANDS

Pause end script

PAUSE_END_COMMANDS

Jam detection and out of filament detection

You can compare filament moves with extruder moves to detect if the extruder is jamming, the spool is knotted or if you are running out of filament. You need a movement tracker, that changes a digital signal every x extrusion steps. There are three steps defined for signaling. Regular steps is what number of steps a complete on/off cycle of the signal should take. While debugging this is the reference for the percent output. Next stage is slowdown steps. When we measure this step amount, we will reduce speed multiplier to a lower factor. Then, when we exceed the steps for jam detection we take a defined action - preferably a pause giving the user a chance to fix the jam and continue printing. See documentation for more informations.

Regular steps for a cycle

JAM_STEPS

[steps]

Slowdown steps

JAM_SLOWDOWN_STEPS

[steps]

Slowdown to
JAM_SLOWDOWN_TO

[%]

**Steps for jam
detection**
JAM_ERROR_STEPS

[steps]

**Min. steps for signal
change**
JAM_MIN_STEPS

[steps]

Jam action
JAM_ACTION

© 2013-2015 Hot-World GmbH & KG | About us (<http://www.repetier.com/about-us/>)